

# INSTALLATION NOTICE

---

## AIR BLEED DIRECTIONS FOR VERTICAL MOUNT CHAMBER



1. INSERT 3/8" ELBOW INTO THE 3/8" FEMALE ADAPTER (SEEN IN FIGURE 1) ON TOP OF THE UV CHAMBER.
2. TAP 3/8" JG NPT VALVE (SEEN IN FIGURE 2) INTO PUMP SUCTION PLUMBING.
3. CONNECT THE TWO POINTS WITH 3/8" TUBING
4. TURN ON POOL PUMP THEN OPEN THE 3/8" JG VALVE.



FIGURE 1



FIGURE 2